


μHDMI

### Input



### Channel pinout

CH 17 - 32

MP1	□	□	MP2
IN22	■	■	IN19
IN23	■	■	IN20
IN30	■	■	IN21
IN31	■	■	IN29
	■	■	
	■	■	
	■	■	
	■	■	
	■	■	IN28
	■	■	
	■	■	IN26
	■	■	
	■	■	IN25
	■	■	
IN27	■	■	IN24
IN18	■	■	
IN17	■	■	IN16
GND	■	■	REF
MP3	□	□	MP4

CH 1 - 16

MP1	□	□	MP2
IN5	■	■	
IN4	■	■	
IN12	■	■	
	■	■	
	■	■	IN10
	■	■	IN11
	■	■	IN2
IN14	■	■	IN3
	■	■	
	■	■	
IN15	■	■	
IN7	■	■	
IN6	■	■	IN8
	■	■	IN9
	■	■	IN0
IN13	■	■	IN1
GND	■	■	REF
MP3	□	□	MP4



Help Desk

